

THE SUREFIRE NO-HASSLE GUARANTEE

We'll do what it takes to keep your SureFire gear running smoothly. SureFire warrants that if you — our customer — purchase one of our products, and we determine that it is defective in material and/or workmanship during your lifetime, we will repair or replace it — no hassle!

Our warranty does not cover consumables or normal wear-and-tear — things like batteries draining, headbands and headpads wearing out, ink cartridges running out, and switches wearing out — or damage resulting from abuse, alterations, unauthorized repairs, or use contrary to SureFire's user manuals.

Should you need a replacement product, Surefire reserves the right to replace an obsolete product with a current production, like model. In the event that any issue with a SureFire product is not covered under this warranty SureFire can arrange to have the product repaired for a reasonable fee.

STANDARD DISCLAIMER

Except as specified above or prohibited by applicable law: all express or implied conditions and warranties, including, without limitation, any implied warranty or condition of merchantability or fitness for a particular purpose, or accuracy of any informational content, are

hereby excluded and disclaimed by SureFire; and in no event will SureFire be liable for any special, direct, indirect, consequential, incidental or punitive damages howsoever arising and regardless of the theory of liability, even if advised of the possibility of such damages. Products, prices, availability, specifications, and offers are subject to change or cancellation at any time without notice.

WARRANTY CLAIMS

For claims, contact Customer Service at 714-545-9444 to obtain a Return Merchandise Authorization number (RMA#). Then package the unit carefully and send to (no CODs):

SureFire, LLC.
Repairs Department, RMA# _____
17680 Newhope, Suite B
Fountain Valley, CA 92708

SureFire will pay any reasonable shipping costs to return the unit to you.


Revision B 1-2018
HS2-MV-A-BK
71-01-999



18300 MT. BALDY CIRCLE,
FOUNTAIN VALLEY, CA 92708
SUREFIRE.COM



MINIMUS™ W/ MAXVISION™ VARIABLE-OUTPUT LED HEADLAMP



FEATURES

1. High-performance LED with faceted MaxVision™ reflector produces a wide, smooth beam optimized to your field of vision.
2. Push button On/Off switch and 13 position variable-light output dial permits one-handed adjustment from 5 to 300* lumens.
3. Hard-anodized aerospace aluminum housing is lightweight and durable.
4. Push button switch retains memory of light output at any of the 13 output settings from previous activation. Press and hold push button switch for 4 seconds in the off position or when light is activated for SOS mode.
5. Custom-made headband utilizes fine mesh material built for comfort, durability, and a secure fit, with or without a helmet.
6. Breathe-O-Prene® pad fits snugly and comfortably against the forehead while wicking away moisture. The pad can be removed for washing or replacement.
7. Leashed battery end cap is built from rugged anodized aluminum.
8. Low-profile headband adjustment clip is rugged yet comfortable.

* Max output for Minimus w/ Maxvision is 300 lumens

US PATENT: 8,066,396

USER MANUAL

MINIMUS w/ MAXVISION HEADLAMP

WE DIDN'T REINVENT THE WHEEL. JUST THE HEADLAMP.


Search & rescue, SWAT, military special operations, and other demanding customers depend on our world-class illumination tools with their very lives. Which is why our engineers created Minimus headlamps—no-compromise LED headlamps designed for exceptional performance and all-night comfort in extreme conditions. It's what you'd expect from Sure-Fire—maker of the world's finest illumination tools.

CONTENTS

- ▶ Headlamp assembly
- ▶ Headband
- ▶ Breathe-O-Prene® pad
- ▶ One SF123A lithium battery
- ▶ One battery end cap

HEADBAND ADJUSTMENT


1. Move buckle towards back of head to tighten and move buckle towards lamp to loosen (Fig. 1).




HEADBAND MAINTENANCE

ATTACHING AND REMOVING THE HEADBAND

1. Stretch headband strap with fingers to make it firmer, thinner, and easier to insert (Fig. 2).




Slide end of headband into side headband mounting slot on side where battery end cap is located (Fig. 3).



2. Slide other end of headband strap through opposite headband mounting slot. *Note: Do not bend or manipulate slot arm(s). This could cause breakage and void your warranty.*
3. Affix Breathe-O-Prene pad to back of light assembly.
4. To remove headband, reverse process outlined above.

BATTERY INSTALLATION/REPLACEMENT

1. Unscrew battery end cap by turning counter clockwise while holding leash.
2. Insert 123A lithium battery into battery compartment in light housing, positive (+) terminal first, as shown in Fig. 3. Dispose of depleted battery (if replacing) properly.




3. Turn battery end cap clockwise, until hand tight, while holding leash.

LIGHT OPERATION

TURNING ON


- Press the On/Off button to activate. Rotate the output adjustment dial in either direction to select one of 13 light output settings. (Fig. 5)



- To achieve maximum output rotate knob clockwise in a rapid movement. Likewise to achieve low level output rotate counterclockwise in a rapid movement.


TURNING OFF

- Press the On/Off button to turn off the light. (Fig. 6)




SOS FEATURE

- Depress and hold the push On/Off button for 4 seconds when the Minimus is off or activated. Depress the On/Off button to turn Off SOS mode. (Fig. 7).



LIGHT ANGLE ADJUSTMENT

The battery housing can be used to adjust the angle of light up or down 90 degrees (Fig. 8).



MINIMUS w/ MAXVISION HEADLAMP

MAINTENANCE

HEAD PAD CLEANING

1. Remove Breathe-O-Prene pad from back of headlamp.
2. Wash with mild hypoallergenic soap and warm water. Allow Breathe-O-Prene pad to air dry.
3. Re-attach Breathe-O-Prene pad.

REMOVE

WASH

DRY




HEADBAND CLEANING

1. Remove headband from rear of headlamp assembly.
2. Machine wash with mild hypoallergenic soap and warm water. Allow headband to air dry.
3. Re-attach headband (see earlier instructions).

REMOVE

WASH

DRY



LED HOUSING AND MOUNT CLEANING

1. To prevent scratching the window, use a soft brush or cotton swab to remove dirt and debris from the protective window, corners of the LED housing, and around the adjustment knobs.
2. Wipe the LED housing with a clean, damp cloth.
3. Do not use harsh solvents to clean LED housing or optic. They may damage these components.

AVAILABLE ACCESSORIES

The following replacement accessories are available from SureFire for the Minimus headlamps:

- Headband
- Breathe-O-Prene pad
- SureFire 123A lithium batteries
- Filters



BATTERY INFORMATION & WARNING

Before replacing batteries, read the enclosed BATTERY INFORMATION/ WARNING insert in your original packaging. For additional battery safety, handling, and product information, visit www.surefire.com/batteries.

THE SUREFIRE NO-HASSLE GUARANTEE

We'll do what it takes to keep your SureFire gear running smoothly. SureFire warrants that if you—our customer—purchase one of our products, and we determine that it is defective in material and/or workmanship during your lifetime, we will repair or replace it for free or refund your money—no hassle! There are just a few exceptions noted below. Electronics, rechargeable batteries, and chargers are warranted for two years from the date of purchase. SureFire hearing-protection products are warranted for 90 days from the date of purchase. Our warranty does not cover consumables or normal wear-and-tear, or damage resulting from abuse, alterations, unauthorized repairs, or use contrary to SureFire's user manuals. To help protect your investment SureFire offers reasonable rates to repair damage to our products not covered by our warranty, such as a core rebuild for a suppressor damaged by improper use.