

WARRANTY

SureFire warrants our suppressors and suppressor related products to be free from defects in workmanship and materials for the lifetime of the original owner. We will repair, replace, or refund your original purchase price of a product if it is determined by SureFire to be defective. This warranty does not cover normal wear and tear, damage to the suppressor resulting in whole or in part from unauthorized repairs, unstable or non-SAAMI/NATO specification ammunition, abuse, misuse, or neglect. Unwarranted repairs to the suppressor, including but not limited to core rebuilds, made necessary by any of these factors will be invoiced to the owner who will be given the right to approve such work before it commences. BSD's and BFA's are designed to be used with blank ammunition only. Any damage due to live fired rounds is not covered by this warranty and cannot be repaired. SureFire assumes no responsibility whatsoever and will honor no claims for damages, regardless of nature, for physical injury or property damage resulting from careless and/or irresponsible handling, adjustments to the suppressor and/or suppressor related products, neglect or abuse.

DISCLAIMER

The above warranties are exclusive, and to the extent permitted by applicable laws, shall be in lieu of all other warranties, expressed or implied, including, without limitation, any warranty of merchantability or fitness for a particular use or purpose. SureFire disclaims any and all liability for product malfunctions, physical injuries, or property damage that result in whole, or in part, from the criminal, negligent, or improper use of the product: and/or from modifications or alterations thereto. In no event shall SureFire be liable for any incidental, special, or consequential damages relating to the purchase, use, or performance of any SureFire product.

WARRANTY CLAIMS

For repair or replacement email Technical Support at technicalsupport@surefire.com or contact Customer Service at 800-828-8809 (toll free) or 714-545-9444 and obtain a Return Merchandise Authorization number (RMA#). An initial request for RMA can also be submitted through the link on www.surefire.com. You may be supplied with additional shipping instructions specific to the product being returned. Package the unit carefully and in accordance with all instructions then return to the mailing address provided (no CODs please). SureFire will pay any reasonable shipping costs to return the unit to you. ©2019 SureFire, LLC. All rights reserved.



18300 MT. BALDY CIRCLE
FOUNTAIN VALLEY, CA 92708-6122
WWW.SUREFIRE.COM

Revision E 07-2020
71-01-1015
SF-SPCR-9
DOPSR REF# 20-S-1556



SUREFIRE®



SPECS	SF RYDER 9 SPACER	
	CONSTRUCTION	Stainless Steel
	LENGTH	1.25 in (3.175 cm)
	WEIGHT	1.2 oz (34 g)

SF RYDER® 9 SPACER

USER MANUAL

SF RYDER® 9 SPACER



INTRODUCTION

The SureFire SF RYDER 9 Fixed Barrel Spacer is to be used for added reliability when firing the SF RYDER 9-Ti and SF RYDER 9M-Ti suppressors on a fixed barrel firearm, typically seen with 9 mm carbines and rifles. This machined stainless steel spacer with short spring restricts the movement of the suppressor for increased reliability and inherent accuracy when firing suppressed. The Fixed Barrel Spacer can be installed in place of the booster spring by following the instructions below.

KIT CONTENTS

- SureFire SF RYDER Fixed Barrel Spacer
- User manual

⚠ WARNING

ALWAYS confirm weapon is unloaded and on SAFE before attempting installation.

INSTALLATION

Piston chamber disassembly, loosen suppressor rear cap with the back end of the Disassembly/Assembly Tool (not pictured) by turning counterclockwise. Remove rear cap then pull piston and spring out of piston housing.

Piston chamber assembly, place piston inside of piston chamber. Place the fixed barrel spacer over the piston shaft with the spring facing rearward toward the open end. Slide rear cap over piston shaft and compress spring so threads on the rear cap engage threads on the suppressor tube. Tighten rear cap fully by turning clockwise until hand tight.

CLEANING

The SF RYDER 9-Ti or SF RYDER 9M-Ti should be cleaned periodically to ensure optimal performance. SureFire recommends cleaning the suppressor piston and fixed barrel spacer at least every 300 rounds. Clean sooner if there is noticeable carbon buildup or any sacrifice in sound attenuation.

